

Edgeport/2 & 4 with RS-232 Point to Point/Asymmetrical



Configuring the Cable Connections (DB9 female)

- 1 - CD
- 2 - RxD
- 3 - TxD
- 4 - DTR
- 5 - signal ground
- 6 - DSR
- 7 - RTS
- 8 - CTS
- 9 - RI